### INSTALLATION INSTRUCTIONS FOR MANUALLY OPERATED PATRIARC MODELS 500 AND 500-R

- 1. Lay the track sections on the floor with the arrow, number and color dot markings facing up. If the track system requires splicing, splice the track sections together by aligning the corresponding numbers on the track sections. To create the center overlap, align the arrow stickers of the track sections making sure that they are pointing towards each other and attach the lap clamps with the hardware provided.
- 2. The live-end and dead-end pulleys can be attached to either end of the track, but the live-end side must always be attached to the forward track section.
- 3. Install the hanging clamps to the top of the track. Note that the maximum separation for the hanging clamps is 5 feet. Install extra hanging clamps in the stack areas, curved areas, and at the ends of the track. The open side of the hanging clamp must face the side of the track which is traversed by the extension arm of the master carrier.
- 4. Attach the cable guides to the top of the track with the clamps and hardware provided. Match the color coded arrows with the color stickers of the guides. <u>Do not</u> tighten down the nylon rollers on the cable guides. Guide spacing is marked at the factory. These marks should be followed as closely as possible. If, because of hanging clamp locations, the cable guides can not be located as indicated by the arrows, they may be moved slightly to either side of the indicated location. If they are moved, be sure to keep the spacing between cable guides the same as the arrows would indicate. Do not exceed this spacing. Additional cable guides are provided for this purpose, should you need them. The guide spacing in a curve, should be symmetrical.
- 5. Install the single and master carriers at the open ends of the track at the center overlap, master carriers last. Be sure to insert the master carrier so that the extension arm, with the cord connector, is on the same side of the track as the open side of the hanging clamps.
- 6. Thread the operating cord over the wheel of the live-end pulley which is in line with the center of the track. Feed the cord between the cable guide rollers to the center overlap. At the center overlap, begin feeding the cord between two outboard cable guide rollers to the dead end pulley. Note that the master carrier has a two piece cable clamp which can be attached to the cable later. Do not cut the cord at the master carriers!
- 7. Feed the cord around the dead end pulley and back towards the center overlap between the center guides. At the overlap, feed the cord through the outboard guide rollers back to the second master carrier. Attach the end of the cord to the cable clamp located on the arm of the master carrier
- 8. Take the other end of the operating cord, feed it through the floor pulley and up over the other wheel of the live-end pulley. Continue cording through the cable guides of the track until you reach the master carrier with the first end of the cord already attached. Loosely attach the cord.

- 9. Raise the track up and secure it in place to the overhead structure. Be sure to use appropriate hardware for attaching the track system to the overhead structure. Attach the floor pulley to the floor making sure that it remains aligned with the live-end pulley attached to the track.
- 10. Move the master carriers to the center overlap making sure that the carriers overlap equally. Disassemble the two piece cable clamp of the master carrier without the cord already attached. Place the operating cord so that the recessed portion of the clamp is directly over the cable. Making certain that the cable is straight, or in line with the recess in the cable clamp, securely tighten the two screws which hold the outer or smaller part of the clamp to the arm of the master carrier. Do not tighten the set screws on the master unless the master carrier is in its proper position.
- 11. Before operating the track, make certain that the cord is in its proper location between all of the cable guides and not under any of the parts which protrude from the track or on the wrong (non-open) side of the hanging clamps.
- 13. Carefully and slowly, operate the track system with the operating cord. If a master carrier should happen to strike a cable guide, loosen the hex nuts which clamp the brackets to the track and move this bracket until the master carrier clears it.
- 14. If the track operates properly, the Allen set screws on the master carriers can be fully tightened.

## **IMPORTANT NOTES**

The span between track supports should never exceed 5 feet. Additional supports should be placed on the curves, splices and the stacking areas.

When the operating cord is threaded through the track, make certain that the cord runs between the cable guides and that it does not run underneath, or on the wrong side of the hanging clamps.

Carrier spacing should never exceed 12 inches.

Minimum curve radius for 5000 series track is 2 feet.

All curved suspended tracks should be additionally supported by 1-1/4" ID stiffening pipe, or the equivalent.

Make certain that the live-end and dead-end pulleys are attached to the overhead structure.

On the curves, make absolutely certain that the cable guides are placed close enough to the hanging clamps so that they will prevent the cable from rubbing the bracket of the

hanging clamps.

When the installation has been completed and is in operation, the curtain should move back and forth without causing any noticeable track deflection.

On tight reverse curved track systems, it may be desirable to link carriers together with chain or cable to facilitate curtain around curves.

When linking carriers together, be sure to allow some fullness in the top of the curtain. If the curtain grommets are spaced 12 inches on center, then the carriers should be linked together on 10 inch centers. Be sure to take this into account when fabricating the curtain so that the curtain will properly cover the opening or screen.

IF THE INSTALLER SHOULD FAIL TO ABIDE BY THESE INSTRUCTIONS, SERIOUS PROBLEMS AND EQUIPMENT DAMAGE MAY OCCUR. THE FACTORY CAN NOT BE HELD RESPONSIBLE FOR ANY DAMAGES WHICH ARISE BECAUSE THE INSTRUCTIONS WERE NOT COMPLIED WITH IN EVERY DETAIL.

### INSTALLATION INSTRUCTIONS FOR MOTORIZED PATRIARC MODELS 500 AND 500-R

- 1. Lay the track sections on the floor with the arrow, number and color dot markings facing up. If the track system requires splicing, splice the track sections together by aligning the corresponding numbers on the track sections. To create the center overlap, align the arrow stickers of the track sections making sure that they are pointing towards each other and attach the lap clamps with the hardware provided.
- 2. The live-end and dead-end pulleys can be attached to either end of the track, but the live-end side must always be attached to the forward track section.
- 3. Install the hanging clamps to the top of the track. Note that the maximum separation for the hanging clamps is 5 feet. Install extra hanging clamps in the stack areas, curved areas, and at the ends of the track. The open side of the hanging clamp must face the side of the track which is traversed by the extension arm of the master carrier.
- 4. Attach the cable guides to the top of the track with the clamps and hardware provided. Match the color coded arrows with the color stickers of the guides. <u>Do not</u> tighten down the nylon rollers on the cable guides. Guide spacing is marked at the factory. These marks should be followed as closely as possible. If, because of hanging clamp locations, the cable guides can not be located as indicated by the arrows, they may be moved slightly to either side of the indicated location. If they are moved, be sure to keep the spacing between cable guides the same as the arrows would indicate. Do not exceed this spacing. Additional cable guides are provided for this purpose, should you need them. The guide spacing in a curve, should be symmetrical.
- 5. Install the single and master carriers at the open ends of the track at the center overlap, master carriers last. Be sure to insert the master carrier so that the extension arm, with the cable connector, is on the same side of the track as the open side of the hanging clamps.
- 6. Thread the operating cable over the wheel of the live-end pulley which is in line with the center of the track. Feed the cable between the cable guide rollers to the center overlap. At the center overlap, begin feeding the cable between two outboard cable guide rollers to the dead end pulley. Note that the master carrier has a two piece cable clamp which can be attached to the cable later. Do not cut the cable at the master carriers!
- 7. Feed the cable around the dead end pulley and back towards the center overlap between the center guides. At the overlap, feed the cable through the outboard guide rollers back to the live-end pulley of the track. Thread the cable over the remaining wheel of the live-end pulley and down to the floor. Coil a few feet of cable on the floor.
- 8. Raise the track up and secure it in place to the overhead structure. Be sure to use appropriate hardware for attaching the track system to the overhead structure. Refer to

ADC Form 745 for instructions on attaching the cable to a grooved drum machine.

- 9. Move the master carriers to the center overlap making sure that the carriers overlap equally. Disassemble the two piece cable clamps of the master carriers. Place the operating cable so that the recessed portion of the clamp is directly over the cable. Making certain that the cable is straight, or in line with the recess in the cable clamp, securely tighten the two screws which hold the outer or smaller part of the clamp to the arm of the master carrier. Do not tighten the set screws on the master unless the master carrier is in its proper position.
- 10. Before operating the track, make certain that the cable is in its proper location between all of the cable guides and not under any of the parts which protrude from the track or on the wrong (non-open) side of the hanging clamps.
- 11. Carefully and slowly, operate the track system MANUALLY with the hand crank of the machine. If a master carrier should happen to strike a cable guide, loosen the hex nuts which clamp the brackets to the track and move this bracket until the master carrier clears it.
- 12. If the track operates properly, the Allen set screws on the master carriers can be fully tightened and the drum of the machine can be engaged.

#### DO NOT MACHINE UNTIL THE LIMIT SWITCHES HAVE BEEN SET.

# **IMPORTANT NOTES**

The span between track supports should never exceed 5 feet. Additional supports should be placed on the curves, splices and the stacking areas.

When the operating cable is threaded through the track, make certain that the cable runs between the cable guides and that it does not run underneath, or on the wrong side of the hanging clamps.

Carrier spacing should never exceed 12 inches.

Minimum curve radius for 5000 series track is 2 feet.

All curved suspended tracks should be additionally supported by 1-1/4" ID stiffening pipe, or the equivalent.

Make certain that the live-end and dead-end pulleys are attached to the overhead structure.

On the curves, make absolutely certain that the cable guides are placed close enough to the hanging clamps so that they will prevent the cable from rubbing the bracket of the hanging clamps.

When the installation has been completed and is in operation, the curtain should move back and forth without causing any noticeable track deflection.

On tight reverse curved track systems, it may be desirable to link carriers together with chain or cable to facilitate curtain around curves.

When linking carriers together, be sure to allow some fullness in the top of the curtain. If the curtain grommets are spaced 12 inches on center, then the carriers should be linked together on 10 inch centers. Be sure to take this into account when fabricating the curtain so that the curtain will properly cover the opening or screen.

IF THE INSTALLER SHOULD FAIL TO ABIDE BY THESE INSTRUCTIONS, SERIOUS PROBLEMS AND EQUIPMENT DAMAGE MAY OCCUR. THE FACTORY CAN NOT BE HELD RESPONSIBLE FOR ANY DAMAGES WHICH ARISE BECAUSE THE INSTRUCTIONS WERE NOT COMPLIED WITH IN EVERY DETAIL.







)5000 TRACK

2)5001 SINGLE CARRIER

3 )5002 MASTER CARRIER

NOTE: CABLE GUIDES MUST BE **INSTALLED ON TRACK AS** PER COLOR CODE SHOWN

4)5003 LIVE END PULLEY						
4 JOUS LIVE END POLLET	AUTOMATIC DEVICES COMPANY					
5 5004 DEAD END PULLEY	2121 S. 12TH ST. ALLENTOWN, PA 18103					
6 5007 LAP CLAMP	THIS DRAWING HAS BEEN PREPARED AS A SERVICE TO OUR CUSTOMER AND IS INTENDED ONLY TO BE SUGGESTIVE IN NATURE AND IS NOT TO BE USED AS AN ACTUAL INSTALLATION DRAWING. PREVAILING JOB CONDITIONS AND ACCEPTED PRACTICES MUST BE TAKEN INTO ACCOUNT WHEN THE EQUIPMENT IS INSTALLED.					
7)5058 CABLE GUIDE	SIZEDATEINSTALLATIONREVA06/08/98INSTRUCTIONS					
8)5058A CABLE GUIDE	DRAWN BYAPPROVED BYDESCRIPTION500TRACKGARASSEMBLY-CONTINUOUS CURVE					
	SCALE NTS SHEET 1 OF 1 DWG NO. II-500CC-98					

RE∨ DATE:



 $\begin{array}{c}
1 \\
2 \\
3 \\
4 \\
5 \\
6 \\
7 \\
8
\end{array}$ 

5000 TRACK

5001 SINGLE CARRIER

5002 MASTER CARRIER

5003 LIVE END PULLEY

5004 DEAD END PULLEY

5007 LAP CLAMP

5058 CABLE GUIDE

5058A CABLE GUIDE

NDTE:

CABLE GUIDES MUST BE INSTALLED ON TRACK AS PER COLOR CODE SHOWN.

	212		UTOMAT 12TH					18103	3	
THIS DRAWING HAS BEEN PREPARED AS A SERVICE TO OUR CUSTOMER AND IS INTENDED ONLY TO BE SUGGESTIVE IN NATURE AND IS NOT TO BE USED AS AN ACTUAL INSTALLATION DRAWING. PREVAILING JOB CONDITIONS AND ACCEPTED PRACTICES MUST BE TAKEN INTO ACCOUNT WHEN THE EQUIPMENT IS INSTALLED.										
size A	date 06/08/98			INSTALLATION INSTRUCTIONS					REV	
DRAWN BY APPROVED BY		DESCRIPTION 500 TRACK								
GAR			ASSEMBLY-REVERSE CURVE							
SCALE	NT	S	SHEET	1 OF	1	DWG NO	<sup>D.</sup> [] –	500RI	2-98	

