



ROSE BRAND

Glassless Mirror Cleaning Instructions:

The film is tough, but can be damaged by fingernails or sharp instruments. If cared for properly, it should last indefinitely. Handle by holding along edges, only *do not* press down on mirror surface with your thumbs when holding mirror along edge. Do not put any weight or object on mirror surface when it is in a horizontal position.

Before attempting to clean the mirror, use dry compressed air to make sure all dust and debris are off the mirror surface (i.e. Dust Off). To easily clean finger marks or splashes, use a window cleaner by wiping gently with a soft, non-abrasive cloth. Any dust or hard particles in the cloth or on the mirror may scratch the film surface. Should the film adhere to the backing panel, blow gently into the vent hole in the back of the panel.

Dimples or wrinkles on Mirror: A heat gun (approx. 300°F temperature) can be used to remove "dimples" or wrinkles from the mirror. Hold the heat gun more than 1" away from the mirror. Keep the heat gun moving in a circular fashion working towards outside edge to avoid burning the mirror film.

Special Note for Scrim Mirror

Do not use Windex on back surface of Scrim Mirror