

## PREPARING SAO SANITIZER SOLUTION



### OPERATING SAO™ DISPENSER

1. Make sure cold water source is available and SAO dispenser is plugged in.
2. Make sure the power switch is OFF.
3. Ensure the SAO bottle or bucket to be filled is on a stable and level surface.
4. Place nozzle into the container and switch the dispenser to ON position.
5. Once READY light turns green, SAO solution is ready to be dispensed.
6. Fill the container, DO NOT OVER FILL.
7. Turn switch to OFF position.
8. Fresh solution should be dispensed daily. Discard any previously unused solution - this old solution can be safely disposed of into a drain.
9. Do not mix SAO solution with any other chemicals (this will render the solution less effective).

*Changing The Way The World Cleans*